

Bat@Edge

Real-time on-device classification of bat and bird calls

Motivation



Scalable solutions for the permanent monitoring of bats are urgently needed.

Acoustic monitoring is THE (non-invasive) method for monitoring bats.

- → **Problem:** Automatic recordings lead to huge amounts of data that have to be analysed retrospectively
 - ◆ Impossible to manage without the help of automatic classification software
 - ♦ Time-consuming reclassification necessary
 - ◆ Large time lag between recording and result
 - Permanent monitoring installations unthinkable at many locations over several years
- → **Solution:** Real-time Al execution on the detectors in the field
 - Enables fast, flexible responses
 - ◆ Reduces data volume
 - Reduces human workload and enables long-term monitoring of multiple sites 24/7



What do we need?

The Bat@Edge Concept

- Al Model for the real-time recognition of bats, birds, amphibs, locusts...
 - needs to be fast, and precise with low computational power demands
- Power-autonomous stations equipped with Al-capable computing unit
- Operating system that allows for real-time data transmission and flexible configuration to reduce data



audio:tracker



Flexibly configurable intelligent real-time audio monitoring system

synchronisation to the cloud


Real-time detection of vocalizing species with the audio:tracker systems The audio:tracker records audio data up to Conversion of the incoming audio ocalisations of different species groups 24 hours a day and analyses the incoming data into a spectrogram audio stream in real time Detection radius Digitised audio data depends on species and terrain characteristics Spectrograms generated every second Storage of recognised Recognition of species-typical vocalisations Further processing of the recognised species and confidence in using runtime-optimised AI algorithms vocalisations: Audio recordings (.flac) for the cloud pre-defined species Visualisation of the data Recognised animal species and confidences Local storage of audio data and optional



audio:tracker




Flexibly configurable intelligent real-time audio monitoring system



audio:tracker




Flexibly configurable intelligent real-time audio monitoring system



Detections are sent COMPLETELY to the backend

The Bat@Edge Concept





YOLO:bat

State of the Art Al Model for the recognition of bat calls

YOLO11 (Ultralytics)

Highest accuracy, speed and efficiency in object detection and classification




YOLO:bat

State of the art AI model for the recognition of bat calls

YOLO11 (Ultralytics)

Highest accuracy, speed and efficiency in object detection and classification




Mehmet Emin Aruk LinkedIn'de: YOLO v11: Temel Düzeyde Görsel Nesne Tespiti Nasıl Yapılır?



YOLO:bat

Results for uncorrelated training and testing (file-based split)

Species	n calls train	n calls test
Mbart	4797	937
Ppip	3297	685
Mdau	2814	767
Mmyo	2623	590
Eser	2491	587
Mnat	2244	641
Pnat	2142	557
Mbec	2068	740
Bbar	1904	423
Malc	1588	382
Mema	1583	332
Ppyg	1496	522
Plecotus	1445	379
Rhip	1300	192
Nlei	904	167
Mdas	838	292
Nnoc	721	166
Rfer	661	213
social-call	83	12
feeding-buzz	71	14



Getting better!




Al is not perfect:

- Needs training data →**YOU!**
- Needs verification by experts →**YOU!**

Currently available:


- On-device AI for real-time classification
- Powerful server AI for the classification of data from other sources (BC, BL, Audiomoth...)
- Annotation tool for validation
 - Verified data goes back to Al
 - Al is constantly improving



Active AI learning process through automatic recognition and interactive validation of vocalizations








40 stations for bird and bat monitoring in the Natura200 area "Hauberge bei Haiger"

- Sunrise to sunset = birds
- Sunset to sunrise = bats

Financed by:








13 (15) Species


Barbastella barbastellus
Pipistrellus nathusii
Pipistrellus pipistrellus
Pipistrellus pygmaeus
Myotis brandtii/mystacinus
Myotis bechsteinii
Myotis daubentonii
Myotis nattereri
Myotis myotis
Nyctalus leisleri
Nyctalus noctula
Eptesicus serotinus
Plecotus austriacus/auritus












Active AI learning process through automatic recognition and interactive validation of vocalizations








Getting better!






Crickets

Getting better!







Real-time processing of animal voices:

- o significantly reduces the amount of data to be analysed
- enables permanent monitoring installations
- allows timely detection of relevant events (migration?)
- is the future of acoustic monitoring

But: Must constantly improve!

Workshop on real-time acoustic ai: 11.02.2025

gottwald@trackit.systems



Thanks to:







Anja Fritzsche

Kseniia Kravchenko

Birgit Gessner

Florian Gloza-Rausch

Thomas Meierkordt

Simon und Widdig

Simon Ripperger

Bernd Ohlendorf

Sarah Heine

Markus Milchram

Joern Horn

Landschaftsökologie

Moritz

...

Thank you!

Jannis Gottwald

Contact

trackIT Systems

Unterm Bornrain 4 +49 157

35091 Cölbe

+49 15783538221

gottwald@trackit.systems

https://trackit.systems

